AirGo Outdoor

Set up is a breeze...

1. Configure the Apple® AirPort Express® per the AirPort Express Manual to suit your network needs.

2. Remove the APX cover using a standard Phillips screwdriver. Be careful not to dislodge the gasket for the APX cover.

3. Remove the detachable electrical prongs from the AirPort Express by sliding the Power Adapter off of the AirPort Express.



4. Take the 3.5mm Audio plug in the APX Pocket and insert it into the Audio Output Jack of the AirPort Express.

5. Insert the power cord from the APX Pocket into the Power Input jack of the AirPort Express.

6. Carefully place the AirPort Express and all of the connected wires into the APX Pocket. Replace the APX cover. Status light illuminates when Airport Express is connected.

7. Plug the Main Power Cord into a grounded electrical outlet. Turn the Power Switch ON and wait for the AirPort Express status light on the APX cover to illuminate.



Russound

Additional installation options and details can be viewed at:
http://AirGo.Russound.com/manual

8. Connect your AirPlay® device to the WiFi network the AirPort Express is setup for, start a music application and select the AirPlay Icon to connect to the AirGo Outdoor.

9. Sit back and enjoy.

©2011 Russound. All rights reserved. PATENT PENDING

Speaker Angle Adjustment



Your AirGo Outdoor is shipped with the speaker in the downward position.

For optimal sound dispersion, adjust the speaker to the upward position before use.

SAFETY INSTRUCTIONS

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS UNIT IN WATER. THE AIRGO OUTDOOR IS WATER RESISTANCE, NOT WATER PROOF. IT IS RECOMMENDED TO HAVE THE UNIT OUTDOORS ONLY WHILE IN USE. IT SHOULD BE STORED INDOOR WHEN NOT IN USE.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Safety Instructions

1. Read Instructions - All the safety and operating instructions should be read before the appliance is operated.
2. Retain Instructions - The safety and operating instructions should be retained for future reference.
3. Heed Warnings - All warnings on the appliance in the operating instructions should be adhered to.
4. Follow Instructions - All operating and user instructions should be followed.
5. Cleaning - The appliance should be cleaned only as recommended by the manufacturer. From time to time you should wipe off the front and side panels and the cabinet with a soft cloth. Do not use rough material, thinners, alcohol or other chemical solvents or cloths since this may damage the finish or remove the panel lettering.
6. Ventilation - The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings, or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings. Place the unit in a well-ventilated location, leaving at least 2 inches (5 cm) of clearance on all sides, top and rear of unit for air flow. If ventilation is blocked, the unit may overheat and malfunction.
7. Heat - The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
8. Grounding or Polarization - Precaution should be taken so that the grounding or polarization means of an appliance is not defeated.
9. Power Cord Protection - Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, receptacles, and the point where they exit from the appliance.
10. Power Sources - The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
11. Main Power Disconnect - The power switch is a single-pole switch. When the switch is in the "Off" position, the appliance is completely disconnected from the main power.
12. Non-Use Periods - The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
13. Attachments - Only use attachments/accessories specified by the manufacturer.
14. Carts and Stands - The appliance should be used only with a cart or stand that is recommended by the manufacturer. An appliance and cart combination should be moved with care. Quick stops, excessive force and uneven surfaces may cause the appliance and cart combination to overturn.

15. Wall or Ceiling Mounting - The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
16. Location of the Appliance - Do not mount this unit under a kitchen cabinet. Do not expose the appliance to heating units as the appliance internal components' temperature may rise and shorten the life of the components. Avoid damp and dusty places.
17. Object Entry - Care should be taken so that objects do not fall into the enclosure through the openings.
18. Servicing - The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.
19. Damage Requiring Service - The appliance should be serviced by qualified service personnel when: A. The power supply cord or the plug has been damaged; B. The appliance does not appear to operate normally; or C. The appliance has been dropped or the enclosure is damaged.

CE TÜV Rheinland of North America, Inc. US

Conforms to UL60065
Certified to CAN/CSA IEC60065

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of or more of the following measures: reorient or relocate the receiving antenna; increase the separation between the equipment and receiver; connect the equipment into an outlet on a circuit different from that to which the receiver is connected, or consult the dealer or an experienced radio/TV technician for help. This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Place Stamp Here

Russound
5 Forbes Road
Newmarket, NH 03857

WARRANTY

The Russound AirGo Outdoor Sound System has a 90 days warranty against defects in materials and workmanship. During the warranty period, Russound will replace any defective part and correct any defect in workmanship without charge for either parts or labor.

Russound may replace returned speakers with a product of equal value and performance. In such cases, some modifications to the mounting may be necessary and are not Russound's responsibility.

For this warranty to apply, the unit must be utilized according to its written instructions. If repairs are necessary, they must be performed by Russound. The unit must be returned to Russound at the owner's expense and with prior written permission. Proof of purchase must accompany all claims. Accidental damage and shipping damage are not considered defects, nor is damage resulting from abuse or from servicing performed by an agency or person not specifically authorized in writing by Russound.

This warranty does not cover:

- Damage caused by abuse, accident, misuse, negligence, or improper operation or installation.
- Products that have been altered or modified.
- Any product whose identifying number or serial number has been altered, defaced, or removed.
- Normal wear and maintenance.

To return for repairs, the unit must be shipped to Russound at the owner's expense, along with a note explaining the nature of service required. Be sure to pack the speaker in the original box or a corrugated container with at least 3 inches of resilient material to protect the unit from damage in transit.

Before returning a speaker for repair, call Russound at 603.659.5170 for a Return Authorization number. Write the RA number on the shipping label and ship to: Russound, ATTN: Service, 5 Forbes Road, Newmarket NH 03857.

Russound sells products only through authorized channels to ensure that customers obtain proper support and service. Any Russound product purchased from an unauthorized dealer or source, will not be honored or serviced under existing Russound warranty policy. Any sale of products by an unauthorized source or other manner not authorized by Russound shall void the warranty on the applicable product.

AirGo™ PRODUCT REGISTRATION

Please register online at http://airgo.russound.com, or fill out and mail this card.

Date of Purchase: _____

Serial Number: _____

Email: _____

Phone: _____

Name: _____

Address: _____

City: _____

State/Province: _____

Zip/Postal Code: _____

Country: _____

©2011 Russound. All rights reserved.
All trademarks are the property of their respective owners. Specifications are subject to change without notice.

Russound is not responsible for typographical errors or omissions.

Russound, Inc.
5 Forbes Road, Newmarket, NH 03857
http://airgo.russound.com

28-1364 **10/06/11, Rev. 1**